

OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

# TRUE FRAME MOUNTED CAMPER TIE DOWNS

IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS

C2206/C2212



REVISED vers6 BY: JL 08/5/15

**TECH SUPPORT (800) 246-8132** 

AFTER INSTALL, PLEASE GIVE
THIS BOOKLET TO YOUR CUSTOMER

# **Warnings**

# **Truck Bed and Camper Protection**

Torklift **does not** recommend installing your camper on top of a plastic bed liner (or other compressible material such as foam). These materials can act as a spring, causing increased vertical truck camper movement independent of the vehicle. Plastic bed liners can slide on the truck bed surface, and the truck camper can slide on top of the bed liner. Using a plastic bed liner or similar compressible material will <u>void your warranty</u> and may additionally cause truck bed and/or camper damage.

Minor movement or settling can occur in some incidental harsh driving conditions (on or off-road). A rubber bed mat is recommended to protect the truck bed and camper, but is not a requirement to maintain the Torklift legendary lifetime warranty.

## **Suspension**

To significantly reduce body roll, sag and sway Torklift strongly recommends the StableLoad. Torklift International StableLoads improve safety, handling, and to help level your truck. More information can be found at (<a href="https://www.Torklift.com/stableload">www.Torklift.com/stableload</a>).

If your truck is additionally equipped with suspension air bags Torklift cautions against over pressurization as this may lead to unsafe vehicle handling characteristics. We have found that airbags used in conjunction with StableLoads have allowed operators to lower air bag pressure by 50% or more. Only pressurize suspension air bags enough to level the truck.

# C2206 / C2212 Parts Inventory

2 - Tie Down Receivers 2 - Straight Inserts

8 - 1/2" Flat Washers 4 - 1/2" Lock Washers

4 - 1/2" Nuts 2 - 1/2" Bolt Fishers

4 - 1/2" x 1-1/2" Hex Bolts 8 - 1/2" Star Washers

2 - 1/4" Pins

- 1. Locate the driver's side tie down receiver and start by disconnecting the emergency brake cable (see Photo 1.1).
- 2. Using the two supplied bolt fishers (refer to page 6), install the two 1/2" x 1-1/2" fasteners with flat and star washers (see Photo 2.4 for correct fastener assembly) into the truck frame (see Photo 2.1, 2.2) and out the two factory holes used for installation (see photo 2.3). Do not remove the bolt fishers, as the bolt will fall into the frame!
- 3. Hold the tie down receiver up into position by first inserting both bolt fisher wires through their respective tie down receiver holes. Allow the bolts to drop back into the frame (leave the bolt fishers attached). Line up the tie down receiver holes with the factory holes in the truck frame and carefully pull the bolts back into position through the tie down receiver (see Photo 3.1).
- **4.** Remove the bolt fishers one at a time, without dropping the bolts back into the frame, and install one 1/2" flat washer followed by one 1/2" lock washer and one 1/2" nut (see Photos 4.1, 4.2 for completed install).
- 5. Install the tie down insert and check for proper truck bed clearance. Tighten all fasteners.
- **6.** Repeat steps 1-5 for passenger's side.

#### **Addendum**

For trucks 2010 and newer:



Bed Mount Reach

**Installation Photos** 

# mstanation i not

Photo 1.1 - Driver's Side




Photo 2.2 - Passenger's Side

Photo 2.1 - Driver's Side



Photo 2.3 - Passenger's Side






Photo 2.4



Photos 3.1 - Passenger's Side




Photo 4.1 - Passenger's Side




Photo 4.2 - Passenger's Side



# TORKLIFT'S BOLT FISHING GUIDE

Your guide to understanding the installation of our frame mounted tie downs.



Desired Hole on Vehicle (Place the coiled end of the bolt fisher through this hole).

This side of the Bolt Fisher should come out of a hole where the required hardware (for example 1" X 2" plate washer) can pass through.



This bottom example shows the bolt when it's completely fished through the vehicle. You may find it easier to keep the bolt fisher attached until you get the tie down receiver in place so that the bolt doesn't fall into the vehicle frame.

WARNING: PULLING TOO HARD ON THE BOLT FISHER CAN RESULT IN LOST FASTENERS, OR BROKEN BOLT FISHER.

# TIEDOWN INSERT INSTALLATION INSTRUCTIONS

On one end of each of your tie down inserts is a triangular plate referred to by Torklift as a bullet plate. Your tie down inserts should be installed with the shorter side of the bullet plate facing away from each other, i.e.. The shorter side of the front insert should point to the front of the truck and the shorter side of the rear insert should point towards the rear of the truck.

Once installed, attach the TorkLift directional stickers to the face of the bullet plate on the insert as a reminder.

## DRIVERS SIDE FRONT

# DRIVERS SIDE REAR





IMPORTANT NOTE: Your tie down inserts are designed to have clearance inside of the receiver. This is to account for road debris, as well as aid in installation and removal. Some rattle may be expected if the inserts are left installed while not under load from the camper.

# INSTRUCTIONS FOR FINISH MAINTENANCE OF TORKLIFT PRODUCTS

#### **POWDER COATED STEEL:**

To keep your Torklift products looking good follow these guidelines. All steel powder coated Torklift products are sandblasted for maximum adhesion and use a high quality industrial urethane based powder coat. Due to the extreme, harsh, undercar environment that your Torklift products live in, (consistently sprayed with corrosive road chemicals such as salt, and road debris), Torklift does not warranty the power coated finish.

To minimize corrosion from these factors on powder coated steel products, Torklift recommends regularly cleaning and inspecting the powder-coated surface and touching up any affected areas with enamel or urethane based aerosol paint product. If there are any areas of surface rust, there are also aerosol spray rust converters available on the market that can be used as a preparation to touch-up paint application. These finish maintenance products are available at any automotive parts supplier.

#### **POLISHED STAINLESS STEEL:**

Torklift utilizes quality grade 304 stainless steel in our stainless steel polished products. 304 stainless steel is well known for its anti-corrosive properties. However, in some environments such as coastal regions or when coming in contact with some road chemicals, corrosion may occur.

For a quick clean simply use WD40 and a cloth rag. We also recommend occasional polishing of our polished stainless products to maintain their attractive finish. Use an approved stainless steel chrome or aluminum mag wheel polish cleaning product, which can be purchased from any automotive parts supplier.

# Torklift International Limited Lifetime Warranty Information

### 322 Railroad Ave North, Kent, WA 98032

Torklift will require proof of purchase to register, with pictures of any defective product before issuing a replacement. Torklift will not register any product without proof of purchase, which can be faxed, scanned, emailed, or mailed to the information provided below. Torklift warrants it's hitches, custom hitch receivers, frame mounted tie downs, turnbuckles, and accessories (excluding wire harnesses which carry a 90 day warranty) from date of purchase against defects in material and workmanship under normal use and service for the ownership life of the original consumer purchaser. ALL COMMERCIAL APPLICATIONS ARE WARRANTED FOR A PERIOD OF 90 DAYS FROM THE DATE OF INSTALLATION/SERVICE. Torklift will replace FREE OF CHARGE any part, which proves defective in material or workmanship when presented to Torklift, TRANSPORTATION CHARGES PREPAID by purchaser, at the address above. THIS WARRANTY IS LIMITED TO DEFECTIVE PARTS REPLACEMENT ONLY. LABOR CHARGES AND/OR DAMAGE INCURRED IN INSTALLATION OR REPLACEMENT, AS WELL AS INCIDENTAL AND CONSEQUENTIAL DAMAGES CONNECTED THEREWITH ARE EXCLUDED. This warranty does not include the finish or paint on our products. Rusting, cracking or peeling of the finish is also excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Any damage to Torklift products as a result of misuse, abuse, neglect, accident, improper installation or any use violation of instructions furnished by Torklift or WHEN USED IN ANY COMMERCIAL APPLICATION WILL VOID THE WARRANTY. This warranty gives you specific legal rights, and you may also have rights, which vary from state to state. With warranty service, you may be able to go to a small claims court, a state court or a federal district court.



# **OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.**

322 Railroad Ave North, Kent, WA 98032 Phone (800) 246-8132 Fax (253) 854-8003

or visit our website: www.TorkLift.com

Dear Valued Customer,

Thank you for making TorkLift your choice for truck, camper packages and accessories for your vehicle. By choosing TorkLift products, you have chosen a company that has been serving the RV industry for nearly 40 years and whose name has become synonymous with strength, quality and advanced design and installation.

Please take a few moments of your time to complete the Product Registration Warranty Card on the next page. When registering your newly purchased TorkLift products, you can be assured that your contact information is secure and that you and your product are getting the attention and respect that you deserve.

Thank you again for choosing TorkLift quality products.

# Register for your lifetime warranty and receive a free Torklift International gift.

To Fax: Send copies of the questionnaire, warranty card and receipt to 253-854-8003

To E-mail: Send copies of the questionnaire, warranty card and receipt to warranty@torklift.com

To Mail: Send to Torklift International 322 Railroad Ave North, Kent, WA 98032



## Frame Mounted Tie Downs

Leading the camper tie down industry in strength, quality, advanced design and installation. TorkLift TRUE frame mounted tie downs are far superior to all tie down systems available.

The TorkLift system is unique in its design and is patented. Four independent tie down points (with no belly or crossbar) working much like your receiver type trailer hitch as the inserts are removable allowing the system to be virtually undetectable when not in use.

They are designed for each make and model to fit tight to the frame so as not to compromise ground clearance. TorkLift tie downs are not universal 'one size fits all' therefore all the problems with correct fit for each particular application have been eliminated.

# Original SuperHitch & SuperHitch Magnum

High strength extended hitch system engineered for safely towing all types of trailers behind your truck and camper. With a max towing capacity of 14,000 lbs(6350Kg). with an extension\*, (17,000 lbs.(7711Kg) to 20,000 lbs.(9071Kg) without\*) the Original SuperHitch and SuperHitch Magnum are rated the strongest in the industry.



#### CONTACT YOUR LOCAL DEALER FOR MORE DETAILS

\*Weight capacity varies depending on the SuperHitch and SuperTruss extension setup.



# OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY. OFFICIAL WARRANTY REGISTRATION CARD

PLEASE FILL OUT THIS FORM COMPLETELY AND RETURN TO TORKLIFT WITHIN 30 DAYS OF PURCHASE ACCOMPANIED BY A COPY OF YOUR ORIGINAL RECEIPT

TODAY'S DATE:	
1. PART(S) PU	RCHASED
	PART#:
	PART#:
2. PURCHASER	INFORMATION
NAME:	_
CITY:	STATE: ZIP / POSTAL CODE:
PHONE: ()	EMAIL:
3. TRUCK INFO	DRMATION MAKE:
MODEL:	BED LENGTH:
4. CAMPER IN	FORMATION
YEAR:	MAKE: MODEL:
5. DEALER INF	FORMATION
PURCHASED FRO	M:
ADDRESS:	
CITY:	STATE: ZIP / POSTAL:
INSTALLED BY:	OWNER ABOVE DEALER ANOTHER DEALER
IF ANOTHER DEA	LER, WHO: