

# 55339

ACURA SLX  
ISUZA TROOPER

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

03/25/09

## English

1. On drivers side locate the grommet in-between the rear tire and bumper under the vehicle location S5. **A**
2. Remove grommet from access hole and locate vehicles taillight wiring harness behind grommet. Insert connector into the vehicles connector being sure they are fully inserted with locking tabs in place.
3. Make a slit in existing grommet so that the wires may pass through. Reseat grommet into access hole.
4. Adhere the black converter box to the frame in a secure out of the way location find a flat clean surface that is out of the path of spray and debris from the rear wheels and road of the vehicle using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.
5. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



55339