

56118 HONDA ODYSSEY

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

12/1/2010

English

1. Open the tailgate and fold the section of the rear seat nearest the driver side forward (A).
 2. Remove (2) cargo hooks from the rear scuff panel. Remove the scuff panel from the vehicle by pulling first forward and then up on it (B,C).
 3. Remove the cargo hook securing the driver side panel. Loosen the panel by gently pulling on it. Remove the fuse panel cover near the rear seat as shown (D,E).
 4. Route the harness connector to the fuse panel starting at the rear of the vehicle, and going behind the interior panel. Insert the harness connector until the locking tab is engaged as shown (F).
 5. Mount the black converter box as shown using the double sided tape provided (G). Insert the 10 AMP fuse provided into the inline fuse holder to complete the install.
- WARNING!**
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.
6. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.
 7. Route the 4 flat along the existing wiring to the center of the vehicle as shown (H). Secure any loose parts wiring harness using the cable ties provided.
 8. Install 10 amp mini fuse provided in position 2 in the fuse panel (F). It is denoted as "Trailer Small LT" on the fuse panel's cover.
 9. Reinstall all items removed during install (I).
 10. Route the harness out of the tailgate when in use. Roll up and store in an out of the way area when not in use.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

