

# 56137

## NISSAN QUEST

### WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



#### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

#### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

1/13/2012

### English

1. Open the rear hatch. On both sides of the vehicle remove both 10 mm bolts holding the taillight assemblies in place (A).
2. On the drivers side locate the vehicles taillight wiring harness connectors behind the vehicles taillight wiring harness assembly. Separate the vehicle's connectors being sure not to damage the connectors (B). Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

#### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

4. Adhere the black converter box to the frame of the vehicle using the double-sided tape provided.

5. Route the 4-flat and the T-Connector end with the green wire down under the vehicle thru the opening under the taillight (C). Route the green wire across to the passenger side along the backside of the bumper and up through the opening under the passenger side taillight. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.

6. Route the 4-flat wire to the center of the vehicle. Secure the 4-flat to the center of the vehicle in a convenient out of the way location. Secure any loose wires with the cable ties provided.

7. Reinstall all items removed during install.

**INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813**



