

56158 HONDA CRV

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

9/13/2012

English

1. Open the hatch. Remove all trunk floor covers (A). Remove the rear scuff panel by removing two plastic fasteners holding it in place then pull up on the top (B),(C). On the driver's side remove the rear cargo loop and two plastic fasteners holding the rear trim panel in place (D).

2. On the driver's side pull back on the rear trim panel to locate the vehicle's taillight wiring harness connectors (E). The connectors will be blue and similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs. Insert the T-Connector end between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (F).

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure the eyelet of the white ground wire using the screw provided.

4. Locate a flat spot and adhere the black converter box to the frame of the vehicle using the double-sided tape provided.

5. Install the 10 amp fuse provided in the fuse holder and install the fuse holder's cap.

6. Route the 4-flat out from under the rear trim panel and to the center of the vehicle when in use. Roll up and store in an out of the way location when not in use.

7. Reinstall all items removed during install.

8. Locate the vehicle's fuse panel under the dash and insert the 10 amp low profile mini fuse into the fuse panel in position 10 (G).



INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

